OWNER'S MANUAL





MARNING!

A Quantum Rehab Provider or a qualified technician must perform the initial setup of this power chair and must perform all of the procedures in this manual.

The symbols below are used throughout this owner's manual and on the power chair to identify warnings and important information. It is very important for you to read them and understand them completely.

№ WARNING!

Indicates a potentially hazardous condition/situation. Failure to follow designated procedures can cause either personal injury, component damage, or malfunction. On the product, this icon is represented as a black symbol on a yellow triangle with a black border.

MANDATORY!

These actions should be performed as specified. Failure to perform mandatory actions can cause personal injury and/or equipment damage. On the product, this icon is represented as a white symbol on a blue dot with a white border.

PROHIBITED!

These actions are prohibited. These actions should not be performed at any time or in any circumstances. Performing a prohibited action can cause personal injury and/or equipment damage. On the product, this icon is represented as a black symbol with a red circle and red slash.

Intended Use

The intended use of the Pride Mobility Products device is to provide mobility to persons limited to a seated position that have the capability of operating a powered wheelchair.

Regarding Devices for Prescription Use

№ WARNING!

CAUTION! Federal law restricts this device to sale by or on the order of a physician or other certified personnel licensed by the law of the State (US only) or region in which this personnel practices to use or order the use of the device.

NOTE: This owner's manual is compiled from the latest specifications and product information available at the time of publication. We reserve the right to make changes as they become necessary. Any changes to our products may cause slight variations between the illustrations and explanations in this manual and the product you have purchased. The latest/current version of this manual is available on our website.

NOTE: This product is compliant with WEEE, RoHS, and REACH directives and requirements.

NOTE: This product meets IPX4 classification (IEC 60529).

NOTE: This product and its components are not made with natural rubber latex. Consult with the manufacturer regarding any after-market accessories.

Quick Reference Information

Quantum Rehab Provider:
Address:
Phone Number:
Purchase Date:




Table of Contents

Introduction	5
Safety	6
Your Power Chair	7
Assembly	9
Comfort Adjustments	13
Batteries and Charging	23
Care and Maintenance	26

Language Usage

This owner's manual is intended for distribution in all Englishspeaking countries where our Power Chairs are sold. We have chosen to compose this manual using language and spellings common to the USA. Since we recognize that not all English-speaking countries use the same words or spellings, please refer to the following chart for some common word variations that may be encountered throughout this manual.

USA	Variation		
asphalt	tarmac		
authorized	authorised		
backward(s)	rearward(s)		
caster	castor		
center	centre		
color	colour		
cord	lead		
counterclockwise	anticlockwise		
curb	kerb		
elevator	lift		
labor	labour		
meter	metre		
path	bridleway; footpath		
pocketbook	handbag		
provider	dealer; agent		
sidewalk	pavement		
tire	tyre		
trunk	boot		
turn signal	turn indicator		
wrench	spanner		
yard	grounds		



Safety

WELCOME to Quantum Rehab. The power chair you have purchased combines state-of-the-art components with safety, comfort, and styling in mind. We are confident that these design features will provide you with the conveniences you expect during your daily activities. Once you understand how to safely operate and care for your power chair, it should give you years of trouble-free operation and service.

Read and follow all instructions, warnings, and notes in this manual before attempting to operate your power chair for the first time. You must also read all instructions, warnings, and notes contained in any supplemental instructional booklets for the controller, front riggings, and/or seating system that accompanied your power chair before initial operation. Your safety depends upon you, as well as your provider, caretaker, or healthcare professional in using good judgment.

If there is any information in this manual which you do not understand, or if you require additional assistance for setup or operation, please contact your Quantum Rehab Provider. Failure to follow the instructions in this manual and those located on your power chair can lead to personal injury and/or damage to the power chair, including voiding the warranty.

Purchaser's Agreement

By accepting delivery of this product, you promise that you will not change, alter, or modify this product or remove or render inoperable or unsafe any guards, shields, or other safety features of this product; fail, refuse, or neglect to install any retrofit kits from time to time provided by Quantum to enhance or preserve the safe use of this product.

Shipping and Delivery

Before using your power chair, make sure your delivery is complete as some components may be individually packaged. If you do not receive a complete delivery, please contact your Quantum Rehab Provider immediately. Where damage has occurred during transport, either to the packaging or content, please contact the delivery company responsible or your Quantum Rehab Provider.

NOTE: If you ever lose or misplace your copy of this manual, contact us and we will be glad to send you a new one immediately.



Product Safety Symbols

The symbols below are used on the power chair to identify warnings, mandatory actions, and prohibited actions. It is very important for you to read and understand them completely.

NOTE: There are more warnings identified and explained in the Consumer Safety Guide that is included with your power chair. Please become familiar with all the warnings and safety information found in the Consumer Safety Guide and refer to this resource often.



Read and follow the information in the owner's manual.

Locked and in drive mode.



Place unit on level ground and stand to one side when changing from drive mode to freewheel mode or freewheel mode to drive mode.

Unlocked and in freewheel mode.



Indicates power chair with similar label is not rated for occupied transit.



Class II Equipment



Manufactured in



Power chair information label



Wire access point. For service use only.



Crush hazard! Keep hands clear.

General Guidelines



MANDATORY!

Do not operate your new power chair for the first time without completely reading and understanding this owner's manual.

Your power chair is a state-of-the-art life-enhancement device designed to increase mobility. We provide an extensive variety of products to best fit the individual needs of the power chair user. Please be aware that the final selection and purchasing decision regarding the type of power chair to be used is the responsibility of the power chair user, who is capable of making such a decision, and his/her healthcare professional (i.e., medical doctor, physical therapist, etc.).

The contents of this manual are based on the expectation that a mobility device expert has properly fitted the power chair to the user and has assisted the prescribing healthcare professional and/or the Quantum Rehab Provider in the instruction process for the use of the product.

There are certain situations, including some medical conditions, where the power chair user will need to practice operating the power chair in the presence of a trained attendant. A trained attendant can be defined as a family member or care professional specially trained in assisting a power chair user in various daily living activities.

As you begin using your power chair during daily activities, you will probably encounter situations in which you will need some practice. Simply take your time and you will soon be in full and confident control as you maneuver through doorways, on and off of elevators, up and down ramps, and over moderate terrain.

Below are some precautions, tips, and other safety considerations that will help you become accustomed to operating your power chair safely.

Pre-Ride Safety Check

Get to know the feel of your power chair and its capabilities. We recommend that you perform a safety check before each use to make sure your power chair operates smoothly and safely.

Perform the following inspections prior to using your power chair:

- Check for proper tire inflation. Maintain but do not exceed the psi/bar/kPa air pressure rating indicated on each tire if equipped with pneumatic tires.
- Check all electrical connections. Make sure they are tight and not corroded.
- Check all controller connections to the power base.
 Make sure they are secured properly.
- Check the brakes. See "Care and Maintenance."
- Check battery charge. See "Batteries and Charging."
- Ensure the manual freewheel levers are in drive mode before sitting on the power chair.

NOTE: If you discover a problem, contact your Quantum Rehab Provider for assistance.

The J4 Power Chair

Your power chair has two main assemblies: the seat assembly and the power base assembly. Typically, the seat assembly includes the armrests, seatback, and seat base. The power base assembly includes two motor/brake assemblies, two drive wheels, four caster wheels, two batteries, and wiring harnesses. **See J4 (page 4) and figure 1.**



The spring tension on your power chair was factory set to meet the needs of the demographic majority of users. Do not adjust the tension of any spring on your power chair.

Electrical Components

The electrical components consist of the controller assembly, the batteries, and the motors. The batteries, motors, and controller power module (if equipped) are located on the power base assembly. The controller is located on the seat assembly. Connectivity between the controller and the motors, batteries, and the battery charger is provided by one or more wiring harnesses. **See figure 1.**

Controller Harness Connector: The controller harness connector is where the controller plugs into the power base. Each controller uses a different type of harness. Regardless of which type of controller is used, the harness must be secured to the seat assembly and not allowed to drag on the floor.

Motor Connectors: This is where the controller connects to the motors.

Battery Connector: This is where the controller connects to the batteries.

Controller Power Module: This enables the controller to communicate with the batteries and the motors.

Main Circuit Breaker (located on the rear main frame): The main circuit breaker is a safety feature built into your power chair. When the batteries and the motors are heavily strained (e.g., from excessive loads), the main circuit breaker trips to prevent damage to the motors and the electronics. If the circuit trips, allow your power chair to "rest" for approximately one minute. Next, push in the circuit breaker button, then turn on the controller, and continue normal operation. If the main circuit breaker continues to trip repeatedly, contact your Quantum Rehab Provider.




Figure 1. J4 Electrical Components

Manual Freewheel Levers

For your convenience, your power chair is equipped with a manual freewheel lever mounted on each motor. The levers allow you to disengage the drive motors and maneuver the chair manually.

WARNING!

Do not use the power chair while the drive motors are disengaged! Do not disengage the drive motors when the power chair is on an incline, as the unit could roll on its own! Only engage the freewheel mode when on a level surface.

MARNING!

Ensure both drive motors are engaged before turning on power to the controller or attempting to drive the power chair because if one motor is in drive mode and the other motor in freewheel mode, the power chair will move in a circle.

Do not attempt to use the power chair or occupy the chair when the drive motors are disengaged.

It is important to remember that when your power chair is in freewheel mode, the braking system is disengaged.

To operate the manual freewheel levers:

- 1. Push down both manual freewheel levers for freewheel mode (drive motor disengaged). **See figure 2.**
- 2. Pull up both manual freewheel levers for drive mode (drive motor engaged). **See figure 2.**

MANDATORY!

You must turn off the power before disengaging the drive motors; otherwise, you may get an error code on the controller. To clear this code, turn off the controller and place the power chair in drive mode. Then, turn on the controller. The error message should be cleared. If it is not, contact your Quantum Rehab Provider.

NOTE: The power chair will be significantly easier to push with the power off.

MARNING!

Avoid applying excessive force to the manual freewheel levers.

Do not use your foot to operate the manual freewheel levers. Do not stand on the manual freewheel levers. Applying excessive force to the manual freewheel levers may result in damage to the freewheel levers, motors, and brakes.

Do not use the freewheel lever handles as tie-down points to secure this product.




Figure 2. Manual Freewheel Lever Operation

Initial Assembly

Your power chair may require some assembly either before initial use or after transportation. It may also require disassembly to make some comfort adjustments. **Figure 3** details those parts of the power chair that are designed to be disassembled and assembled by an end user or by a qualified caregiver before using the product or making comfort adjustments.

NOTE: Any nylon insert lock nut removed during the disassembly or adjustment of the power chair must be replaced with a new nut. Nylon insert lock nuts should not be reused as it may cause damage to the nylon insert, resulting in a less secure fit. Replacement nylon insert lock nuts are available at local hardware stores or through your Quantum Rehab Provider.

Seat Installation

It may be necessary to install the seat either prior to initial operation or after transporting your power chair. Contour seats are attached to the power base with the Universal Mounting System (UMS). The UMS consists of universal parts that may be attached to the seat, regardless of seat width or seat depth. The two main components are aluminum extrusions mounted to the seat base. These extrusions attach to a pair of trapeze bars that are mounted to the power base. **See figure 4 or 6.**

NOTE: If your power chair is equipped with a TB-Flex Seat or a Q4 Seat Power Positioning System, refer to the information provided in separate manuals.

WARNING!

Do not pick up the seat frame by the armrests. They are free to pivot, and you may lose control of the seat if they do so.




Figure 3. Assembly View of J4

To install the seat:

- Tilt the seat back and align the interfaces on the bottom rear of the seat with the rear seat securement brackets on the power base and secure with the hardware. See figure 4.
- 2. Pivot the seat down and secure the front seat interface into the top of the actuator with the detent pin.

MARNING!

Make sure the hardware and detent pin are properly secured before using your power chair.

3. Install the controller and route the harness to the back of the power base. **See figure 1.**

MANDATORY!

Prevent controller harness damage! Avoid routing the controller harness on the outside of the armrest pad. Route the harness under the armrest or toward the inside of the armrest pad. Use correct tie-down points for controller harness to prevent the harness from getting caught in the drive tires, pinched in the seat frame, or damaged when passing through doorways.

- 4. Plug the controller connector into the rear of the power base. **See figure 1.**
- 5. Secure the controller harness to the armrest receiver with wire ties. **See figure 5 or 7.**




Figure 4. Mounting System and Contour Seat




Figure 5. Controller Harness Routing on TB-Flex Seat

To install the seat:

- Tilt the seat back and slide the rear extrusion onto the rear trapeze bar. See figure 6.
- Lower the front extrusion onto the front trapeze bar until the seat latches into place.
- Flip the seat latch safety down.

WARNING!

Make sure the seat latch safety is flipped down before using your power chair.

Install the controller and route the harness to the back of the power base. See figure 5 or 7.

MANDATORY!

Prevent controller harness damage! Avoid routing the controller harness on the outside of the armrest pad. Route the harness under the armrest or toward the inside of the armrest pad. Use correct tie-down points for controller harness to prevent the harness from getting caught in the drive tires, pinched in the seat frame, or damaged when passing through doorways.

- Plug the controller connector into the rear of the power base. See figure 1.
- 6. Secure the controller harness to the armrest receiver with wire ties. See figure 5 or 7.




Figure 6. Universal Mounting System




Figure 7. Controller Harness Routing on Contour Seat

If your power chair is equipped with a transit securement system, it is equipped with manufacturer-installed front and rear securement brackets, and may be equipped with positioning belt anchoring brackets. **See figure 8.** Refer to the supplement provided with your power chair for information on how to use the transit securement system.

Power Chair Securement Points

The power chair may be equipped with four (4) tie-down points for the purpose of securing the unoccupied power chair during motor vehicle transport. Each tie-down is clearly labeled for this purpose.

To secure a power chair equipped with tie-down points:

- Always secure the power chair in a forward-facing position in the vehicle.
- Attach the four (4) tie-down straps to only designated, labeled transit securement points indicated by anchor symbols on the power chair. See figures 8 and 9. Tighten the straps sufficiently to remove all slack.
- Never attach tie-downs to adjustable, moving, or removable parts of the power chair such as armrests, front riggings, and wheels.
- Position the anchor point for the rear tie-down straps directly behind the rear securement points on the power chair. The front tie-down straps should be anchored to floor points that are spaced wider than the power chair to provide increased stability. See figure 9.

MANDATORY!

The power chair should be used as indicated in the manufacturer's instructions. If you have any questions about the proper use of your power chair, contact your Quantum Rehab Provider.




Figure 8. Transit System Securement Brackets




Figure 9. Unoccupied Transit System Securement Points

Comfort Adjustments

After becoming familiar with your power chair's operation, you may find the need to make some adjustments to increase your comfort, such as seat height and angle, armrest width, angle, and height, foot platform height, depth, and angle, and controller position.

NOTE: If your power chair is equipped with a TB-Flex Seat or a Q4 Seat Power Positioning System, refer to the seat adjustment information contained in separate manuals.

MARNING!

The center of gravity of your power chair was factory set to a position that meets the needs of the demographic majority of users. Your Quantum Rehab Provider has evaluated your power chair and made any necessary adjustments to suit your specific requirements. Do not change your seating configuration without first contacting Quantum Rehab or your Quantum Rehab Provider.

Some power chair components are heavy. You may need assistance to lift or carry them. Please refer to the specifications table for specific component weights before you disassemble the power chair.

Remove the occupant from the power chair before making any adjustments.

You may need the following to make comfort adjustments:

- metric/standard socket set and ratchet
- adjustable wrench
- metric/standard hex key set
- thread lock

Manual Recline Seatback Adjustment

Your seat may be equipped with a manual recline lever that allows you to adjust the seatback angle.

To adjust the seatback angle:

- 1. Pull the adjustment strap on the bottom portion of the seatback. **See figure 10.**
- 2. Set the seatback at the desired angle for operator comfort.
- 3. Release the adjustment strap when the seatback is at the desired angle.




Figure 10. Manual Recline Seatback Adjustment

NOTE: If your power chair is equipped with a TB-Flex Seat or a Q4 Seat Power Positioning System, refer to the seat adjustment information contained in separate manuals.

Seat Angle (Dump) Adjustment

Your seat may be equipped with mechanism that allows you to adjust the seat angle (dump) from -5° to +21° in 2.5° increments. See figure 11.

NOTE: The exact tilt angle adjustment range may vary depending on seating system and seat height.

NOTE: For more information on operating the power positioning systems, refer to the information supplied in supplemental manuals or contact your Quantum Rehab Provider.

Seat Height Adjustment

Your seat may be adjusted to one of three heights.

To adjust the seat height:

- Remove the occupant from the power chair.
- Remove the detent pin from the front seat interface. See figure 4.
- 3. Pivot the seat rearward and remove the seat from the power base by removing the hardware that attaches the rear seat securement brackets to the interfaces on the bottom of the rear of the seat. See figure 4.
- Remove the hardware that attaches the rear seat securement brackets to the power base.
- 5. Adjust the seat to the desired height.
- 6. Reinstall the hardware that attaches the rear seat securement brackets to the power base.
- 7. Reinstall the hardware that attaches the rear seat securement brackets to the interfaces on the bottom of the rear of the seat.
- Reinstall the front seat interface to the top of the tilt actuator using the detent pin. See figure 4.

Seat Width Adjustment

You can adjust the seat width from 16 in. to 20 in. (40.6 cm to 50.8 cm). See figure 12.

NOTE: Changing the armrest width may increase the overall width of your power chair.

To adjust the seat width:

- Remove the seat cushion.
- Loosen the armrest receiver hardware.
- 3. Reposition the armrest receiver to the desired seat width.
- 4. Tighten the armrest receiver hardware.
- 5. Adjust the width of the other armrest if necessary.
- Replace the seat cushion.




Figure 11. Seat Angle (Dump) Adjustment




Figure 12. Seat Width Adjustment

Leg Rest Width Adjustment

You can adjust the leg rest width from 16 in. to 20 in. (40.6 cm to 50.8 cm). See figure 13.

To adjust the leg rest width:

- 1. Remove the seat cushion.
- 2. Loosen the leg rest receiver hardware.
- 3. Reposition the leg rest receiver to the desired seat width.
- 4. Tighten the leg rest receiver hardware.
- Adjust the width of the other leg rest if necessary.
- Replace the seat cushion.

Armrest Height Adjustment

You can adjust the armrest height. The height adjustment range is 3 in. (7.62 cm) in 1-in. (2.54-cm) increments.

To remove the armrest assembly:

- 1. Pull out the armrest lock lever. See figure 14.
- Lift up the armrest assembly.

To install the armrest assembly:

- 1. Place the armrest assembly into the armrest lock. See figure 14.
- 2. Push in the armrest lock lever.

To adjust the top height:

- 1. Pull out the armrest lock lever. See figure 14.
- 2. Pull up or push down the armrest to the desired position.
- 3. Push in the armrest lock lever.
- 4. Repeat for the other armrest if necessary.



Figure 13. Leg Rest Width Adjustment




Figure 14. Armrest Removal/Installation and Top Height Adjustment

NOTE: If your power chair is equipped with a TB-Flex Seat or a Q4 Seat Power Positioning System, refer to the seat adjustment information contained in separate manuals.

WARNING!

The center of gravity of your power chair was factory set to a position that meets the needs of the demographic majority of users. Your Quantum Rehab Provider has evaluated your power chair and made any necessary adjustments to suit your specific requirements. Do not change your seating configuration without first contacting Quantum Rehab or your Quantum Rehab Provider.

Some power chair components are heavy. You may need assistance to lift or carry them. Please refer to the specifications table for specific component weights before you disassemble the power chair.

Remove the occupant from the power chair before making any adjustments.

You may need the following to make comfort adjustments:

- metric/standard socket set and ratchet
- adjustable wrench
- metric/standard hex key set
- thread lock

Seat Height and Seat Angle Adjustment

If your power chair is not equipped with a transit securement system, you can change the seat height to one of three positions by raising the front and rear trapeze bars. If you raise or lower only one trapeze bar (front or rear), you can also change the seat base angle (dump).



If your power chair is equipped with a transit securement system and any adjustment to the seat height or seat angle is necessary, contact your Quantum Rehab Provider. These comfort adjustment can only be made by a Quantum Rehab Provider.

To change the seat height:

- 1. Turn off the power to the controller.
- Make sure the power chair is in drive mode.
- Unplug the controller connector(s) from the power base. See figure 1.
- 4. Flip up the seat latch safety. See figure 6.
- Squeeze the seat latch and release the seat from the front trapeze bar.
- Slide the seat forward and remove it from the power base.
- Remove the hardware that attaches the trapeze bars to the seat interface weldments. See figure 15.
- Move the trapeze bars up or down to the desired height.

NOTE: Change the seat dump by raising or lowering only one trapeze bar (front or rear).

- Reinstall the hardware.
- 10. Reinstall the seat.
- 11. Reconnect the controller to the power base.




Figure 15. Seat Height/Angle Adjustment

Seat Position

You can move the seat forward or rearward by changing the extrusion mounting position.

To change the position:

- 1. Turn off the power to the controller.
- 2. Make sure the power chair is in drive mode.
- 3. Unplug the controller connector(s) from the power base.
- 4. Remove the seat from the power base.
- Remove both extrusions from the bottom of the seat.
- Reposition the extrusions on a different set of mounting holes. You must move both extrusions the same number of holes either forward or backwards. See figure 16.
- 7. Fasten the extrusions back onto the bottom of the seat.
- 8. Reinstall the seat.
- 9. Reconnect the controller to the power base.

Armrest Width Adjustment

You can change each armrest's width independently of the other.

NOTE: Changing the armrest width may increase the overall width of your power chair.

To change the armrest width:

- 1. Locate the two armrest knobs on each side of the armrest receiver bracket. **See figure 17.**
- 2. Loosen the knobs.
- 3. Slide the armrests in or out to the desired width.
- 4. Tighten the knobs.

Armrest Angle Adjustment

To change the armrest angle: 1 Lift the armrest straight up so the

- 1. Lift the armrest straight up so that it is perpendicular to the floor. **See figure 17.**
- 2. Loosen the jam nut.
- Turn the adjusting screw to raise or lower the front of the armrest.
- 4. Tighten the jam nut to lock the adjusting screw into place.

Armrest Height Adjustment

To change the armrest height:

- 1. Loosen the two setscrews located on the armrest receiver. **See figure 17.**
- 2. Raise or lower the armrest to the desired height.
- 3. Tighten the setscrews to secure the armrest.




Figure 16. Seat Position Adjustment




Figure 17. Seatback, Armrest, and Controller Adjustment

NOTE: If your power chair is equipped with a TB-Flex Seat or a Q4 Seat Power Positioning System, refer to the seat adjustment information contained in separate manuals.

Controller Position

You can move the controller in toward or out away from the armrest, or change the position of the controller for either left-hand or right-hand use.



Prevent controller harness damage! Avoid routing the controller harness on the outside of the armrest pad. Route the harness under the armrest or toward the inside of the armrest pad. Use correct tie-down points for the controller harness to prevent the harness from getting caught in the drive tires, pinched in the seat frame, or damaged when passing through doorways.

To change the controller position:

- 1. Turn off the power to the controller.
- 2. Unplug the controller connector from the rear of the power base. **See figure 1.**
- 3. Remove any wire ties securing the controller harness to the armrest.
- 4. Loosen the adjustment knob on the armrest where the controller is currently located. **See figure 18.**
- 5. Relocate the controller to the desired armrest and tighten the adjustment knob to secure the controller.
- 6. Use wire ties to secure the controller harness to the armrest.
- 7. Route the controller harness to the front of the power base and reconnect the controller. **See figure 19.**




Figure 18. Controller Position




Figure 19. Cable Routing

MARNING!

Do not place the controller harness so that it can be pinched in the seat frame or the power base frame.

To extend the controller:

- 1. Flip up the armrest so it is perpendicular to the floor.
- 2. Loosen the setscrew on the controller bracket. **See figure 17.**
- Slide the controller into or out of the armrest to the desired position.
- Tighten the setscrew to secure the controller.

To change the controller position:

- 1. Turn off the power to the controller.
- 2. Unplug the controller connector(s) from the power base.
- 3. Remove any wire ties securing the controller harness to the armrest.
- 4. Flip up the armrest so it is perpendicular to the floor.
- 5. Loosen the setscrew on the controller bracket.
- 6. Slide the controller out of the armrest.
- Loosen the setscrew in the other armrest.
- Place the controller in the other armrest.
- 9. Tighten the setscrews in both armrests.
- 10. Route the controller harness to the back of the power base and plug in the controller.
- 11. Secure the controller harness to the armrest with wire ties. See figure 5 or 7.

NOTE: If your power chair is equipped with a TB-Flex Seat or a Q4 Seat Power Positioning System, refer to the seat adjustment information contained in separate manuals.

Foot Platform Height Adjustment

The foot platform height is easily adjusted to several different heights.

To raise or lower the foot platform:

- 1. Remove the hardware from the foot platform bracket. See figure 20.
- 2. Raise or lower the foot platform to the desired height.
- 3. Reinstall the hardware into the foot platform bracket and tighten.

Foot Platform Depth Adjustment

You can adjust the depth of the foot platform.

To adjust the foot platform depth:

- 1. Remove the hardware from the foot platform bracket. See figure 20.
- Move the foot platform in or out to the desired depth.
- 3. Reinstall the hardware into the foot platform bracket and tighten.




Figure 20. Foot Platform Adjustment

Foot Platform Angle Adjustment

You can adjust the angle of the foot platform.

To adjust the foot platform angle:

- 1. Flip up the foot platform and locate the screw. **See** figure 20.
- 2. Turn the screw to raise or lower the front of the foot platform.

Positioning Belt

Your power chair may be equipped with a positioning belt that can be adjusted for operator comfort. **See figure 21, 22, or 23.** The positioning belt is designed to support the operator so that he/she does not slide down or forward in the seat. The positioning belt is not designed for use as a restraining device.

MARNING!

The positioning belt is not designed for use as a seat belt in a motor vehicle. Nor is your power chair suitable for use as a seat in any vehicle. Anyone traveling in a vehicle should be properly belted into seats approved by the vehicle manufacturer.

The positioning belt should be secured at all times. Never allow the positioning belt to hang or drag on the floor as it may become entangled.

To install the positioning belt:

- 1. Remove the rearmost screw that holds the seat hinge to the seat base on both the left and right seat hinges.
- Insert the screw through the supplied washer, through the positioning belt and into the seat base for each side of the power chair seat.
- 3. Tighten both screws.

NOTE: If your power chair is equipped with an optional seating system, please refer to the user manual provided with the seat for instructions on positioning belt installation or contact your Quantum Rehab Provider.

To adjust the positioning belt for operator comfort:

- Once seated, insert the metal tab on one side of the belt into the plastic housing on the opposite side until you hear a click.
- 2. Pull the excess strap attached to the metal tab until it is secure, but not so tight as to cause discomfort.

To release the positioning belt:

1. Press the push button mechanism on the plastic housing.



Make sure the positioning belt is properly secured to the power chair and is adjusted for operator comfort before each use.

Inspect the positioning belt for loose parts or damage, including tears, worn spots, bent hardware, damaged latch mechanisms, dirt or debris, before each use of the power chair. If you discover a problem, contact your Quantum Rehab Provider for maintenance and repair.




Figure 21. Positioning Belt Adjustment




Figure 22. Positioning Belt Installation and Adjustment– Configuration A




Figure 23. Positioning Belt Installation and Adjustment–Configuration B



Power Positioning Systems Adjustment

Your power chair may be equipped with a power recline, power tilt or power elevating leg rest system. You can change the position of these options through the controller.

MARNING!

Do not allow the motor to run more than a few seconds after the mechanism reaches the top or bottom limit.

NOTE: For more information on operating the power positioning systems, refer to the information supplied in supplemental manuals or contact your Quantum Rehab Provider.

MARNING!


The power positioning systems are intended for use on a level surface only. Never operate your power chair while tilted or reclined on an inclined surface. Failure to heed this warning can result in the power chair tipping over.

Never operate your power chair while tilted or reclined on bumpy or uneven surfaces. Failure to heed this warning can result in the power chair tipping over.

Never operate the power positioning systems while your power chair is in the freewheel mode.

Always fasten the positioning belt when operating the power positioning systems.

Pinch Point Hazard! Keep area around actuator clear when operating the power positioning systems or returning to your starting position.






Figure 24. NE and NE+ Controllers

Batteries and Charging

The J4 uses two long-lasting, 12-volt, deep-cycle batteries. These batteries are sealed and maintenance-free. Since they are sealed, there is no need to check the electrolyte (fluid) level. Deep-cycle batteries are designed to handle a longer and deeper discharge. Though they are similar in appearance to automotive batteries, they are not interchangeable. Automotive batteries are not designed to handle a long, deep discharge, and also are unsafe for use in power chairs.



Battery posts, terminals, and related accessories contain lead and lead compounds. Wear goggles and gloves when handling batteries and wash hands after handling.

WARNING!

Contact your Quantum Rehab Provider if you have any questions regarding the batteries in your power chair.

PROHIBITED!

Always use two batteries of the exact same type, chemistry, and amp-hour (Ah) capacity. Refer to specifications table in this manual and in the manual supplied with the battery charger for recommended type and capacities.

Charging the Batteries

The battery charger is essential in providing long life for your power chair batteries. It is designed to optimize your power chair's performance by charging the batteries safely, quickly, and easily.



PROHIBITED! Removal of grounding prong can create electrical hazard. If necessary, properly install an approved 3-ponged adapter to an electrical outlet having 2-pronged plug access.



PROHIBITED! Never use an extension cord to plug in your battery charger. Plug the charger directly into a properly wired standard electrical outlet.



PROHIBITED! Do not allow unsupervised children to play near the power chair while the batteries are charging. Quantum Rehab recommends that you do not charge the batteries while the power chair is occupied.



MANDATORY! Read the battery charging instructions from this manual and in the manual supplied with the battery charger before charging the batteries.



WARNING! Explosive gases may be generated while charging the batteries. Keep the power chair and battery charger away from sources of ignition such as flames or sparks and provide adequate ventilation when charging the batteries.



WARNING! You must recharge the power chair batteries with the supplied off-board battery charger. Do not use an automotive-type battery charger.



WARNING! Inspect the battery charger, wiring, and connectors for damage before use. Contact your Quantum Rehab Provider if damage is found.



WARNING! Do not attempt to open the battery charger case. If the battery charger does not appear to be working correctly, contact your Quantum Rehab Provider.



WARNING! Be aware that the battery charger case may become hot during charging. Avoid skin contract and do not place on surfaces that may be affected by heat.



WARNING! If the battery charger is equipped with cooling slots, then do not attempt to insert objects through these slots.





WARNING! If the battery charger has not been tested and approved for outdoor use, then do not expose it to adverse or extreme weather conditions. If the battery charger is exposed to adverse or extreme weather conditions, then it must be allowed to adjust to the difference in environmental conditions before use indoors. Refer to the manual supplied with the battery charger for more information.

To charge the batteries using the off-board charger:

- Position your power chair next to a standard electrical outlet
- 2. Be certain the controller power is turned off and the power chair is in drive mode.
- 3. Plug the off-board charger into the off-board charger/ programming socket on the controller. **See figure 25.**
- 4. Plug the off-board charger into the electrical outlet.

MARNING!

The LED lights on the charger indicate different charger conditions at various times: charger power on, charging in progress, and charging complete. If the LED does not indicate that charging is complete within 24 hours, unplug the charger from the outlet and contact your Quantum Rehab Provider. Refer to the manual supplied with the charger for a complete explanation of these indicators.

5. When the batteries are fully charged, unplug the off-board charger from the electrical outlet and then from the controller.

Battery Break-in

To break in new batteries for maximum efficiency:

- 1. Fully recharge any new battery prior to its initial use. This brings the battery up to about 90% of its peak performance level.
- 2. Operate your power chair throughout the house and yard. Move slowly at first, and do not travel too far until you become accustomed to the controls and break in the batteries.
- 3. Give the batteries another full charge of at least 8 to 14 hours and operate your power chair again. The batteries will now perform at over 90% of their potential.
- 4. After four or five charging cycles, the batteries will top off at 100% charge and last for an extended period.

Frequently Asked Questions (FAQs)

How does the charger work?

The battery charger takes the standard electrical outlet voltage (alternating current) and converts it to 24V DC (direct current). The power chair batteries use direct current to run your power chair. When the battery voltage is low, the charger works harder to charge the battery. As the battery voltage approaches full charge, the charger does not work as hard to complete the charging cycle. When the battery is fully charged, the amperage from the charger is nearly at zero. This is how the charger maintains a charge but does not overcharge the battery.

Can I use a different battery charger?

You should use the charger supplied with the power chair. It is the safest, most efficient tool to charge the batteries. We do not recommend using other types of chargers (e.g., an automotive battery charger).




Figure 25. Battery Charger

NOTE: Your power chair's charger will not operate after the batteries have been discharged to nearly zero voltage. If this happens, call your Quantum Rehab Provider for assistance.

How often must I charge the batteries?

Many factors come into play when deciding how often to charge the batteries. You may use your power chair all day on a daily basis or you may not use it for weeks at a time.

Daily Use

If you use your power chair on a daily basis, charge the batteries as soon as you are finished using your power chair. Your power chair will be ready each morning to give you a full day's service. It is recommended that you charge the batteries at least 8 to 14 hours after daily use. We recommend that you charge the batteries for an additional 4 hours after the battery charger indicates that charging is complete.

Infrequent Use

If you use your power chair infrequently (once a week or less), you should charge the batteries at least once per week for at least 24 hours.

NOTE: Keep your batteries fully charged and avoid deeply discharging your batteries. Refer to the manual supplied with the battery charger for charging instructions. We recommend charging your batteries for at least 48 continuous hours once per month to improve battery performance and battery life.

How can I get maximum range or distance per charge?

Rarely do you have an ideal driving situation such as smooth, flat, hard terrain with no wind, hills, or curves. More often you are presented with hills, sidewalk cracks, uneven and loosely packed surfaces, curves, and wind. All of these factors will affect the distance or running time per battery charge. Below are a few suggestions for obtaining the maximum range per charge:

- Always charge the batteries fully prior to your trip.
- Plan your trip in advance to avoid inclines if possible.
- Limit baggage weight to essential items.
- Try to maintain an even speed and avoid stop-and-go driving.
- We recommend charging your batteries for at least 48 continuous hours once per month to improve battery performance and battery life.

What type of batteries should I use?

We recommend deep-cycle batteries that are sealed and maintenance free. Both AGM and Gel-Cell are deep-cycle batteries that are similar in performance. Refer to the specifications table for more information regarding the batteries used with your power chair.



Corrosive chemicals contained in batteries. Use only AGM or Gel-Cell batteries to reduce the risk of leakage or explosive conditions.

Why do my new batteries seem weak?

Deep-cycle batteries employ a much different chemical technology than that used in car batteries, nickel-cadmium (nicads), or in other common battery types. Deep-cycle batteries are specifically designed to provide power, drain down their charge, and then accept a relatively quick recharge. AGM and Gel-Cell batteries should be charged as often as possible. They do not have a "memory" like nickel-cadmium batteries.

We work closely with our battery manufacturer to provide a battery that best suits your power chair's specific demands. Fresh batteries arrive regularly at Quantum and are promptly shipped with a full charge. During shipping, the batteries encounter temperature extremes that may influence initial performance. Heat robs the charge from the battery, and cold slows the power available and extends the time needed to recharge the battery (just as with a car battery).

It might take a few days for the temperature of the battery to stabilize and adjust to its new ambient temperature. More importantly, it will take a few "charging cycles" (a partial drain—then a full recharge) to establish the critical chemical balance that is essential to the battery's peak performance and long life. It will be well worth it to take the time to break in your battery properly.

How can I ensure maximum battery life?

A fully charged deep-cycle battery will provide reliable performance and extended battery life. Keep your power chair's batteries fully charged whenever possible. Batteries that are regularly and deeply discharged, infrequently charged, or stored without a full charge may be permanently damaged, causing unreliable power chair operation and limited battery life.

NOTE: The useful life of a battery is quite often a reflection of the care it receives.

How should I store my power chair and its batteries?

If you do not use your power chair regularly, we recommend maintaining battery vitality by charging the batteries at least once per week.

If you do not plan on using your power chair for an extended period, fully charge the batteries prior to storage. Disconnect the battery harnesses and store the power chair in a warm, dry environment. Avoid temperature extremes, such as freezing and excessively hot conditions, and never attempt to charge a frozen battery. A cold or frozen battery should be warmed for several days prior to recharging.

What about public transportation?

AGM and Gel-Cell batteries are designed for application in power chairs and other mobility vehicles. These batteries are Federal Aviation Administration (FAA) approved, allowing safe transportation on aircraft, buses, and trains, as there is no danger of spillage or leakage. We suggest you contact the carrier's ticket counter in advance to determine that carrier's specific requirements.

What about shipping?

If you wish to use a freight company to ship your power chair to your final destination, repack your power chair in the original shipping container and ship the batteries in separate boxes.

Care and Maintenance

Your J4 is a sophisticated power chair. Like any motorized vehicle, it requires routine maintenance checks. You can perform some of these checks, but others require assistance from your Quantum Rehab Provider. Preventive maintenance is very important. If you follow the maintenance checks in this section as scheduled, you can help ensure that your power chair gives you years of trouble-free operation. If you have any doubt as to your power chair's care or operation, contact vour Quantum Rehab Provider.

WARNING!

Do not service the power chair when the seat is occupied.

Your power chair, like most electrical equipment, is susceptible to damage from the elements. Avoid damp areas of any kind.

/N (🖎 WARNING!

Direct or prolonged exposure to water or dampness could cause the power chair to malfunction electronically and mechanically. Water can cause electrical components to corrode and the chair's frame to rust. Power chairs should be examined periodically for signs of corrosion caused by water exposure, bodily fluid exposure, or incontinence. Damaged components should be replaced or treated immediately.

Should your power chair come in contact with water:

- Dry your power chair as thoroughly as possible with a towel.
- 2. Allow your power chair to sit in a warm, dry place for 12 hours to allow unseen water to evaporate.
- 3. Check the joystick operation and the brakes before using your power chair again.
- 4. If any inconsistencies are found, take your power chair to a Quantum Rehab Provider. Power chairs that are frequently exposed to sources of water, such as incontinence, should be inspected often for corrosion and electronic components may need to be replaced frequently.

Temperature

- Some of the parts of your power chair are susceptible to extreme changes in temperature. Always keep your power chair between the temperatures of 18°F (-8°C) and 122°F (50°C).
- In extremely cold temperatures the batteries may freeze. The specific temperature at which they freeze depends on a number of factors, such as battery charge, usage, and composition of the batteries (e.g., AGM or Gel-Cell).

General Guidelines

- Avoid knocking or bumping the controller, especially the joystick.
- Avoid prolonged exposure of your power chair to extreme conditions, such as heat, cold, or moisture.

- Keep the controller clean.
- Check all connectors to ensure that they are all tight and secured properly.
- Make sure pneumatic tires are inflated to the psi/bar/kPa air pressure rating indicated on the tire.

/ WARNING!

Make sure your tires are inflated to the psi/bar/kPa air pressure rating indicated on the tire for pneumatic tires. Do not under inflate or over inflate your tires. Low pressure may result in loss of control, and overinflated tires may burst. Overinflating tires can cause them to explode.

Do not use a high pressure hose to inflate your tires.

Use a rubber conditioner on the tire sidewalls to help preserve them.

∕!\ WARNING!

Never use a rubber conditioner on the tread area of the tires; doing so may make the tires slippery and cause your power chair to skid.

- All wheel bearings are prelubricated and sealed. They require no subsequent lubrication.
- If your power chair has a body shroud with a glossy finish, the body shroud has been sprayed with a clear sealant coating. You can apply a light coat of car wax to help it retain its high-gloss appearance. If your power chair has a body shroud with a **matte finish**, use ONLY products developed for matte-finish paint. Do not use wax, detail spray, ArmorAll®, or any product made for glossy paint.

WARNING!

Carefully choose the correct product to protect the finish of your power chair's shroud(s). ONLY products developed for matte-finish paint should be used on shrouds with a matte finish. Failure to follow this warning may result in damage to the shroud's matte paint finish.

Check all electrical connections. Make sure they are tight and are not corroded. Batteries must sit flat within the battery tray, with the battery terminals facing rearward. Refer to the battery wiring label for the correct wiring layout.

M WARNING!

Even though the power chair has passed the necessary testing requirements for ingress of liquids, you should keep electrical connections away from sources of dampness, including direct exposure to water or bodily fluids and incontinence. Check electrical components frequently for signs of corrosion and replace as necessary.

Daily Checks

- With the controller turned off, check the joystick. Make sure it is not bent or damaged and that it returns to the neutral position when you release it. Check the rubber boot around the base of the joystick for damage. Visually inspect the boot. Do not handle or try to repair it. See your Quantum Rehab Provider if there is a problem.
- Visually inspect the controller harness. Make sure that it is not frayed, cut, or has any wires exposed. See your Quantum Rehab Provider if there is a problem.
- Check for flat spots on solid tires. Flat spots could adversely affect stability.
- Inspect the seating system, armrests, and front riggings for loose hardware, stress points, or damage. See your Quantum Rehab Provider if there is a problem.

Weekly Checks

- Disconnect and inspect the controller from the power base. Look for corrosion. Contact your Quantum Rehab Provider if necessary.
- Ensure that all parts of the controller system are securely fastened to your power chair. Do not overtighten any screws.
- Check for proper tire inflation. Pneumatic tires should be inflated to the psi/bar/kPa air pressure rating indicated on each tire. If a tire does not hold air, see your Quantum Rehab Provider for replacement of the tube.
- Check the brakes. This test should be carried out on a level surface with at least 3 feet (1 meter) of clearance around your power chair.

To check the brakes:

- Turn on the controller and turn down the speed level of your power chair.
- After one second, check the battery condition meter. Make sure that it remains on.
- Slowly push the joystick forward until you hear the electric brakes click. Immediately release the joystick. You must be able to hear each electrical brake operating within a few seconds of joystick movement. Repeat this test three times, pushing the joystick backward, then left, and then right.

Monthly Checks

- Check for drive tire wear. See your Quantum Rehab Provider for repair.
- Check the caster wheels for wear. Replace them as necessary.
- Check the caster forks for damage or fluttering which indicates that they may need to be adjusted or have the bearings replaced. See your Quantum Rehab Provider for repair.
- Check the entire power chair for loose hardware and changes in the function or performance of the power chair. See your Quantum Rehab Provider for service or repair.

- Keep your power chair clean and free of foreign material, such as mud, dirt, hair, food, drink, etc.
- Spring shocks and gas dampers should be visually checked for any abnormality, structure damage, or bent rods. See your Quantum Rehab Provider for repair.

Yearly Checks

Take your power chair to your Quantum Rehab Provider for yearly maintenance, especially if you use your power chair on a daily basis. This helps ensure that your power chair is functioning properly and helps prevent future complications.

Storage

Your power chair should be stored in a dry place, free from temperature extremes. When storing, disconnect the batteries from the power chair. See "Batteries and Charging."

⚠ WARNING!

If you fail to store the unit properly, the frame can rust and the electronics can be damaged. Any corroded electronic connection should be replaced.

Batteries that are regularly and deeply discharged, infrequently charged, stored in extreme temperatures, or stored without a full charge may be permanently damaged, causing unreliable performance and limited service life. It is recommended that you charge the batteries periodically throughout periods of prolonged storage to ensure proper performance.

You may wish to place several boards under the frame of your power chair to raise it off of the ground during periods of prolonged storage. This takes the weight off the tires and reduces the possibility of flat spots developing on the areas of the tires contacting the ground.

Disposal of Your Power Chair

Your power chair must be disposed of according to applicable local and national statutory regulations. Contact your local waste disposal agency or Quantum Rehab Provider for information on proper disposal of power chair packaging, metal frame components, plastic components, electronics, batteries, neoprene, silicone, and polyurethane materials.

/N WARNING!

Plastic bags are a suffocation hazard. Dispose of plastic bags properly and do not allow children to play with them.

Cleaning and Disinfection

- Use a damp cloth and mild, non-abrasive cleanser to clean the plastic and metal parts of your power chair. Avoid using products that may scratch the surface of your power chair.
- If necessary, clean your product with an approved disinfectant. Make sure the disinfectant is safe for use on your product before application.

MARNING!

Follow all safety instructions for the proper use of the disinfectant and/or cleaning agent before applying it to your product. Failure to comply may result in skin irritation or premature deterioration of upholstery and/or power chair finishes.

Never hose off your power chair or place it in direct contact with water. Your power chair has a painted, ABS plastic body shroud that allows it to be easily wiped clean with a damp cloth.

Never use any chemicals to clean a vinyl seat, as they may cause the seat to become slippery or dry out and crack. Use soapy water and dry the seat thoroughly.

Wheel Replacement

If you have pneumatic tires and you have a flat tire, you can replace the tube. If your chair is equipped with a solid tire insert, then you must replace the entire wheel assembly. Replacement tires, tubes, and wheel assemblies are readily available through your Quantum Rehab Provider.

MARNING!

The wheels on your power chair should only be serviced or replaced by a Quantum Rehab Provider or a qualified technician.

Be sure that the controller's power is turned off and the power chair is not in freewheel mode before performing this procedure.

When changing a tire, remove only the five lug nuts, then remove the wheel. If any further disassembly is required, deflate the tire completely or it may explode.

Follow these easy steps for a quick and safe repair for both pneumatic and solid tires:

- Turn off the power to the controller.
- 2. Set the power chair up on blocks.
- 3. If you are changing a pneumatic tire, completely deflate it before removing the wheel.
- 4. Remove the five (5) lug nuts from the wheel hub. **See figure 26.**
- 5. Pull the wheel off of the hub.
- 6. Remove the screws and separate the front and rear rim. See figure 27.
- 7. Remove the old tube from the pneumatic tire and replace it with a new tube or replace the entire assembly if it is a solid tire.
- 8. Screw together the two rim halves.
- 9. Slide the wheel back onto the hub.
- 10. Reinstall the five (5) lug nuts onto the wheel hub and tighten
- 11. Inflate the pneumatic tire to the psi/bar/kPa air pressure rating indicated on each tire.
- 12. Remove the power chair from the blocks.




Figure 26. J4 Drive Wheel




Figure 27. J4 Drive Wheel Disassembled

Battery Replacement

A battery wiring diagram is printed on a decal located on the front cover. See the specification table for correct battery specifications.



Battery posts, terminals, and related accessories contain lead and lead compounds. Wear goggles and gloves when handling batteries and wash hands after handling.

⚠ WARNING!

The batteries in your power chair should only be serviced or replaced by a Quantum Rehab Provider or a qualified technician.

Do not replace batteries when seat is occupied.

Power chair batteries are heavy. See specifications table. If you are unable to lift that much weight, be sure to get help. Use proper lifting techniques and avoid lifting beyond your capacity.

Do not mix old and new batteries. Always replace both batteries at the same time.

PROHIBITED!

Keep tools and other metal objects away from the battery terminals. Contact with tools can cause electrical shock.

To replace the batteries:

- 1. Turn off the power to the controller.
- Make sure that the power chair is in drive mode. See "Your Power Chair."
- Loosen the rear pivot hardware until the nylon insert lock nut is a few threads from being removed.
- 4. Remove the detent pin from the top of the actuator. See figure 4. If there is any difficulty in reaching the pin from under the seat, the seat pan may be removed. Remove six (6) Phillips flat head screws to remove the seat pan.
- 5. Pivot the seat toward the rear of the power chair and support the seat in this position. Take care to ensure that the recline actuator does not damage the rear door of the power chair while the seat is pivoted rearward.
- Remove the front cover by squeezing the release handles (see figure 28) and lifting the front cover up and away from the power base.
- 7. Remove the top cover by lifting it straight up and off of the power chair.
- Disconnect the actuator harness.
- 9. Disconnect the quick release battery connectors. **See figure 1.**
- 10. Remove the front battery from the power base by sliding it forward and out of the power base.
- 11. Remove the rear battery by lifting it up and out of the power base.
- 12. Disconnect the battery harness from each battery.

- 13. Connect the battery harness to the new front battery according to the battery wiring diagram. **See figure 28.**
- 14. Connect the battery harness to the new rear battery according to the battery wiring diagram. **See figure 28.**

MARNING!

Make sure you tighten the fasteners so that the connections are secure.

- 15. Install the new rear battery by lowering it into the power base. Ensure the actuator is straight up and down next to the rear battery. Connect the quick release battery connectors to the new rear battery.
- 16. Install the new front battery by sliding it into the front of the power base. Connect the quick release battery connectors to the new front battery.
- 17. Reinstall the top cover by sliding the rear of the top cover under the lip of the rear door and then sliding into place.
- 18. Reinstall the front cover.
- 19. Return the seat to an upright position.
- 20. Reinstall the detent pin into the top of the actuator and ensure that it is secure. **See figure 4.**
- 21. Reinstall six (6) Phillips flat head screws if seat pan was removed.
- 22. Tighten the rear pivot hardware.
- 23. Charge the batteries. See "Batteries and Charging."




Figure 28. Battery Installation

When to See Your Quantum Rehab Provider for Service

The following symptoms could indicate a serious problem with your power chair. If necessary, contact your Quantum Rehab Provider. When calling, have the model number, serial number, nature of the problem, and the error code if available.

- Motor noise
- Frayed harnesses
- Cracked or broken connectors
- Uneven wear on any of the tires
- Jerky motion
- Pulling to one side
- Bent or broken wheel assemblies
- Does not power up
- Powers up, but does not move
- Loose seat or seating components

Corrective Maintenance

If the battery condition meter does not light up when you turn on the power:

- Check the harness connections. Make sure they are
- Check the circuit breaker. Reset it if necessary.
- Check the battery connections.

If the above conditions prove normal, you can load test the batteries with a battery load tester. These testers are available at automotive parts stores. Disconnect both batteries before load testing and follow the directions that come with the load tester. If either one of the batteries fails the load test, replace both of them. If your power chair still does not power up, contact your Quantum Rehab Provider.



USA

401 York Avenue Duryea, PA 18642

Canada

5096 South Service Road Beamsville, Ontario L0R 1B3

Australia

20-24 Apollo Drive Hallam, Victoria 3803 www.quantumrehab.com.au

New Zealand

38 Lansford Crescent Avondale Auckland, New Zealand 1007 www.pridemobility.co.nz

UK

32 Wedgwood Road Bicester, Oxfordshire OX26 4UL www.quantumrehab.co.uk

B.V.

(Authorised EU Representative)
De Zwaan 3
1601 MS Enkhuizen
The Netherlands
www.quantumrehab.eu

Italy

Via del Progresso, ang. Via del Lavoro Loc. Prato della Corte 00065 Fiano Romano (RM) www.quantumrehab-italia.it

France

26 rue Monseigneur Ancel 69 800 Saint-Priest www.quantumrehab.fr

Spain

Calle Velazquez 80 6D 28001 Madrid

www.quantumrehab.com

Serial #

