

# Power Bases and Options Available with WC-19 Occupied Transit

## BASE MODELS

Q6 Edge® 2.0  
4Front®  
Q6 Edge® Z  
Q6 Edge® (N/A with lift)  
Q6 Edge® HD (Synergy Seat only)  
Edge 3  
Q6 Edge® 2.0 X  
J4

## SEATING SYSTEMS

TRU-Balance® 3 Static\*  
TRU-Balance® 3 Power Tilt\*  
TRU-Balance® 3 Power Recline\*  
TRU-Balance® 3 Power Tilt & Recline\*  
TRU-Balance® 3 Lift/Power Tilt/Power Recline  
Captain's Seat (Q6 Edge® 2.0, Q6 Edge® 2.0 X and Edge 3)  
Synergy® Seat  
Q4 Tilt

SEAT SIZES	SEAT-TO-FLOOR HEIGHTS	BACK TYPE	ARMRESTS
Overall back height: 12"-28" Static/tilt/recline and tilt & recline (12"-22" Wide and 12"-22" Deep) Lift, iLevel® (15"-20" Wide and 14"-20" Deep) Q6 Edge® HD (20"-24" Wide and 16"-24" Deep)	AVAILABLE ON ALL	TRU-Balance® 3 back Back canes ADI Back	TRU-Balance® 3 flip-back standard and tube style Flip-up height adj. (Captain) 2-post armrests Gel Armpads

## FOOT RIGGING

70-degree swing away footrests (straight, short tapered or tapered)      Adjustable center mount foot platform - all configurations  
Center mount articulating foot platform - all configurations      Misc. accessories (calf pads, calf panels, heel loops, and foot boxes)

## HEADRESTS

Stealth® Comfort Plus Headrest with removable mounting hardware or offset headrest  
Stealth® 8", 10" or 14" Comfort Plus Headrest Pad

## LAP BELT

60" non-retractable lap belt with transit lap belt mount (**mandatory**)

## ACCESSORIES

Swing away joystick mount	Attendant control	Push handles	Sip-n-puff modules
Stealth® UniLink Pelvic/Thigh Guides	Fender lights	Egg switches	ARM 250
Stealth® lateral thoracic supports	Cup holder	Side mount egg switch bracket	ARM 260
Stealth® elbow supports	Accessory bar	Glove box	T-slot accessory block
Stealth® hip/thigh guides	Enhanced Display	Cell phone holder	TB4 electronics accessory mounting bracket
USB XLR charger	Military Patch	SCIM module	TRU-Comfort 2, skin protection & CoolCore® positioning cushions
USB charger port (corded)	Weather Cover	Toggle iAccess iAccess Quad push button	

**NOTE:** Optimizing instructions and Occupied Transit owner's package are sent when the Occupied Transit configuration is selected.

\* Available with or without iLevel®