

Power Bases and Options Available with WC-19 Occupied Transit

BASE MODELS

Edge 3 Stretto®	Edge® HD (Synergy® Seat only)
Edge® 2.0	Q6 Edge® 2.0 X
4Front® 2	J4
4Front® 2 HD	J4 HD
Edge® Z	J6 (Captain's Seat only)
Edge® 3	

SEATING SYSTEMS

TRU-Balance® 3 Static*	TRU-Balance® Flex Seating
TRU-Balance® 3 Power Tilt*	TRU-Balance® Flex Static Seating
TRU-Balance® 3 Power Recline*	TRU-Balance® Flex Pediatric Tilt
TRU-Balance® 3 Power Tilt & Recline*	Synergy® Seat
TRU-Balance® 3 Power Lift with iLevel®	Q4 Tilt
TRU-Balance® 3 Lift/PowerTilt/Power Recline	Captain's Seat

BACK TYPE

BACK OPTIONS

ARMRESTS

FOOT RIGGING

Newly redesigned TRU-Balance® 3 back	ADI Back Q-Back	TRU-Balance® 3 flip-back standard and tube style Flip-up height adj. (Captain)	70-degree swing away footrests Center mount articulating foot platform - all available configurations
Back canes (flip-forward N/A)	TRU-Comfort Sport	2-post armrests Pediatric removable armrests Single-post armrests HD removable armrests Flip-back cane-mounted armrests Height-adjustable drop in T armrests	Adjustable center mount foot platform - all available configurations Misc. accessories

SEAT-TO-FLOOR HEIGHTS

HEADRESTS

LAP BELT

AVAILABLE ON ALL	Stealth® 8", 10" or 14" Comfort Plus Headrest Pad Stealth® removable, offset, or UniLink™ hardware 6", 8", 10" and 14" coolcore headrest pad	60" non-retractable lap belt with transit lap belt mount (mandatory)
------------------	--	---

ACCESSORIES

Accessory bar ARM 250 ARM 260 Arm pouch Attendant control Dual saddle bag Egg switches Enhanced display Fender lights Foam armpads	Gel armpads Glove box iAccess Military patch Privacy flaps Quad push button Quantum® backup camera SCIM module Side mount egg switch bracket Sip-n-puff modules	Stealth® UniLink™ lateral thoracic supports Stealth® elbow supports Swing away joystick mount T-slot accessory block Toggle iAccess Transfer handles TRU-Comfort 2 cushions USB XLR charger USB charger port (corded) Weather cover
---	--	--

NOTE: Optimizing instructions and Occupied Transit owner's package are sent when the Occupied Transit configuration is selected.

* Available with or without iLevel®