

Joystick Operation Guide



This is how your joystick works if it is the standard programming. There are many adjustments that can be made so always ask your therapist or provider and we can work to make it optimal for you.

Video: https://youtu.be/AtY2U4qH6HE



Push joystick forward: will go to driving screen

Push joystick left: will go to settings menu

Pull joystick reverse: will go to seating menu

For more detailed information see the owners guide:


https://www.quantumrehab.com/pdf/basic-operation-instructions/us q-logic3 boi om.pdf

Drive indicator:

Green= good to drive and at full speed

Yellow = inhibited speed but will drive

Red = Will not drive (typically means your power seating is moved in a position not approved to drive. Move seating functions until you get a green button.



"M" Mode: drive profiles, settings, then seating

Drive profiles: There are 4 standard but these can be customized by the speeds of each or choose to have fewer drive profiles






Settings Menu: you won't need to go in here often but on helpful thing is once in the menu give a left joystick command to get to provider information. Then move joystick right to select and it will give you the serial number of the chair.









Seating: will discuss these functions on the next page





If you push up and hold: bottom arrow will highlight and chair will move towards an upright position



If you pull down and hold: top arrow will highlight and chair will move towards a backward tilted position



If you move the joystick right or left (either direction is fine) it will scan through your seating options.


Example:



Recline



Legs move out/in



Recline and Legs together



What Do Your Seating Functions Do?





 Tilting your chair back is recommended for pressure relief: every 30 mins for 2 mins all the way back 50 degrees





- Recline is typically used to open the back rest angle a little when upright
- When performing your pressure relief: tilt all the way, then recline ~20 degrees. When returning upright: come out of recline THEN out of tilt to upright





- Raising and lowering legs to reposition
- Can also raise your legs when tilted back in your chair which may help with leg swelling





 Recline and legs together can be used to reposition your hips and knees and also to lay out for rest or functional tasks like dressing





- When elevated up you will see this "eye" symbol and will go to a safer speed
- Elevating allows great access to your environment or can be used to help transfer





- Raising and lowers your footplate closer to the ground or closer to the seat pan
- Can be utilized for transfers or to improve foot placement for accessibility

AFP Articulate (TB4 units only)



Anterior Tilt (TB4 units only)



- Tilts your seat into a forward direction
 - Can be utilized for transfers, functional reach, or position change in an anterior direction
 - You chair will show an "A" in the green circle when in an anterior position



Memory 1 of 4 (TB4 units only)

- This indicates a customized position for your
- It may be specifically labeled for an activity you perform or have a number icon
- This is custom for things like:
 - Transfers
 - Getting into a vehicle
 - Functional tasks like cooking or eating
 - Leisure activities like fishing
 - Etc.

QL3E Joystick

Video: https://youtu.be/08u00ArKer8



Icon button functions:

- Can have multiple pages with 3 functions on each
- Your icons will change and could show things like:
 - Power seating functions
 - Speed up/down
 - Settings
 - Puddle lights
- If you have more than 3 selections you will press the button



Mode Profiles:

Your drive profiles are set with different speed ranges in each. These can be customized or you can choose to have less than 4 just ask your therapist or wheelchair provider about these options. D= drive. To change drive profiles you press the button.

If you have the + or – button available these allow you to increase or decrease speed within that profile.



Mode profiles continued:

Settings: You can push the "M" mode button to access various options







Settings: You can push forward to go into your settings



Brightness



Horn Volume



Beep Volume



Settings: you can use left and right joystick movements to scan to the option you would like



Once on the setting you would like to change push forward (+) or pull reverse (-) to increase or decrease that setting

Mode profiles continued:





Bluetooth: utilized by your chair provider or if you have a Bluetooth item paired





Information: pushing your joystick forward will provide the serial number of the chair which may be needing in the future.





Seating:

Moving the joystick right or left with change what is highlighted orange on the chair (different seating functions); pushing joystick forward or pulling back will activate that power seating function

Seating:

This will vary based on what power seating functions are on your chair. Whatever is highlighted orange is what will move.

You move your joystick right or left to change what is highlighted.





Tilt:

Tilting your chair back is recommended for pressure relief: every 30 mins for 2 mins all the way back 50 degrees

If you have the availability of anterior tilt it will look like this with an A indicator:





Recline:

Recline is typically used to open the back rest angle a little when upright

When performing your pressure relief, you could tilt all the way, then recline. When returning upright: come out of recline THEN out of tilt to upright.



Seat Elevator:

When elevated up you will see this "eye" symbol and will go to a safer speed

Elevating allows great access to your environment or can be used to help transfer/reach




Power Legs:

Raising and lowering legs to reposition behind your knees

Can also raise your legs when tilted back in your chair which might help with leg swelling or positioning




You will push forward and hold or pull reverse and hold and feel the power seating function move.



*If your seating options show up in your page menu you can **press and hold the button** bellow it (seat function will more in one direction)

Release, and press and hold again (seat function will move in other direction)



Additional Menu Icons:

